

# Conector de alimentación continua para Sony NP-BX1



**Marca:** Otro  
**Código:** CON-OTR-0009  
**Disponibilidad:** En Stock

**Precio:** \$51.34

## Descripción

Conector de corriente continua para Sony:

modelos de cámara compatibles: DSC-RX1 (DSC-RX1R), DSC-RX100, DSC-RX100M II (DSC-RX100M2), DSC-RX100 III (DSC-RX100M3), DSC-RX100 IV (DSC-RX100M4)

Conéctese directamente al banco de energía (5 V, 2 A) para uso en interiores y exteriores.

Entrada de alimentación USB: 5 V, 2 A; Salida DC: 4,2 V El paquete incluye: 1 \* acoplador DC DK-X1; Cable de alimentación USB DC de 1 \* 1,5 M

## Especificaciones

| Características        |        |
|------------------------|--------|
| Alimentación           | USB    |
| Compatibilidad Batería | NP-BX1 |
| Para                   | Sony   |

## Product Gallery



## Installation Steps:



Step 1: Open the battery compartment and unlock the reserved power cable outlet of the camera



Step 2: Make sure you put the external DC battery pack in right direction



Step 3: Close the battery compartment and put the power cable through the reserved power cable outlet



Step 4: Connect USB DC Cable to the Power Supply. (Note: Please use a high quality power supply and output guarantee of at least 2A current.)